GB USER MANUAL

UNIVERSAL REMOTE CONTROL

Thank you for purchasing this universal remote control. Before using the remote you will need to insert 2 type "AAA" batteries (not included) in the battery compartment ensuring that you follow the polarity shown on the inside. You can now use your remote control to operate up to 9 different devices (depending on the model) including a TV, video recorder, DVD player, satellite or cable receiver, CD player, tuner (radio), tape recorder and amplifier. If your remote control is equipped with an AUX key (not standard on all models) then you can also use it to control a second TV set, video recorded, satellite receiver and/or cable box, CD player, tuner, tape recorder or amplifier!

Easy programming for the control of your TV SET

1. Insert 2 new 1.5V alkaline batteries of type "AAA/LR03". Observe battery polarity as indicated in the battery compartment.
2. Switch on your TV SET.
3. In the enclosed code list, find your TV brand or manufacturer (e.g. Sony).
4. Beside the manufacturer's name, you will find one or more 3-digit codes. These codes must be entered into the remote to enable it to work with your particular TV set.
5. Press the TV key on the remote control for approximately 4 seconds until the LED flashes twice.
6. After seeing the 2 flashes and within 5 seconds, enter the 3-digit numerical code from the list.
7. After entering the code the LED will flash twice indicating that the code has been accepted.
8. Point the remote control towards your TV and press the ⏻ key. If your TV does not respond by going into Stand-By mode then repeat steps 3 to 8 and enter the next code in the list.
9. If your TV goes into Stand-By mode when the ⏻ key pressed then your remote control has found a compatible code. Next test all of the other function buttons. If certain functions are not working correctly then restart the process moving onto the next code number as this may well improve the situation.
10. If the codes in the list fail to operate your TV then next move onto the automatic code scan function (see below).

Easy programming for the control of your VIDEO RECORDER

To programme the remote control to operate your VIDEO RECORDER, proceed as described above for the television set. Complete steps 1 to 10 using the VCR key on your remote control. Please ensure that you refer to the codes listed under the VIDEO RECORDER section and not the TV section.

Easy programming for the control of your SATELLITE RECEIVER

To programme the remote control to operate your SATELLITE RECEIVER or CABLE BOX, proceed as described for the television set. Complete steps 1 to 10 using the SAT key on your remote control. Please ensure that you refer to the codes listed under the SATELLITE section and not the TV section.

Easy programming for the control of your DVD PLAYER

To programme the remote control to operate your DVD PLAYER, proceed as described for the television set. Complete steps 1 to 10 using the DVD key on your remote control. Please ensure that you refer to the codes listed under the DVD section and not the TV section.

Easy programming for the control of your CD PLAYER

To programme the remote control to operate your CD PLAYER, proceed as described for the television set. Complete steps 1 to 10 except you must first press and release the SHIFT key followed by holding down the CD key. Please ensure that you refer to the codes listed under the CD section and not the TV section.

Easy programming for the control of your TUNER (RADIO)

To programme the remote control to operate your TUNER, proceed as described for the CD PLAYER but using the TUNER key instead of the CD key. Please ensure that you refer to the codes listed under the TUNER section and not the CD PLAYER section.

Easy programming for the control of your TAPE RECORDER (TAPE DECK)

To programme the remote control to operate your TAPE RECORDER, proceed as described for the CD PLAYER but using the TAPE key instead of the CD key. Please ensure that you refer to the codes listed under the TAPE section and not the CD PLAYER section.

Easy programming for the control of your AMPLIFIER

To programme the remote control to operate your AMPLIFIER, proceed as described for the CD PLAYER. Complete steps 1 to 10, using the AMP key on your remote control. Please ensure that you refer to the codes listed under the AMPLIFIER section and not CD PLAYER section.

Code scan

If programming using the codes in the enclosed list failed to work then you must next try the automatic code scan.

A. Ensure that the remote control is equipped with 2 new batteries (see step one of easy programming procedure).
B. Switch on your TV SET. When using the automatic scan function for the VCR, DVD, CD or TAPE, switch on your device, insert a video tape, DVD, CD or tape cassette and put the unit into 'Play mode' i.e, the VCR tape etc is running.
C. Press the TV key of your remote control for approx. 4 seconds until the LED flashes twice.
D. After seeing the 2 flashes and within 5 seconds, enter the code 0 0 1. After entering the code the LED will flash twice indicating that the code has been accepted
E. Press and hold the ⏻ key until your TV switches off. Please note that this process might take up to 15 minutes. During the automatic scanning you can remove your finger or change hands provided it is replaced within 8 seconds. If left off of the key for more than 8 seconds then the remote will revert back to its normal mode. If your TV switches into Stand-By mode during the automatic process then immediately remove your finger from the ⏻ key and then press and release the TV key until the LED flashes twice, this will then store the code that the remote has found
F. In some cases during the automatic scanning search the remote control might find several codes that appear to operate your TV etc, however, if some of the buttons fail to work properly then it's possible the remote has found a partially compatible code. In such cases you will need to restart the automatic scanning process (steps B. to F.) until a better code is found. Please note that once the automatic process is restarted, the remote continues from the last stored code and not at the beginning of code database.
   - To complete a code scan for the VCR, DVD, CD or TAPE, follow the procedure above but use the ■ key and not the ⏻ key
   - To complete a code scan for the TUNER, follow the procedure above but use the key 7

Code scan for VCR, SAT, DVD, CD, TAPE, TUNER and AMP

To complete a code scan for VCR, SAT, DVD, CD, TAPE, TUNER or AMP, proceed as described for a TV code scan. Complete above steps A to G, using keys
VCR / SAT or DVD, or
SHIFT and CD / SHIFT and TAPE / SHIFT and TUNER or SHIFT and AMP respectively.
At step E,
for SAT and AMP, press the ⏻ key;
for VCR, DVD, CD and TAPE, press the ■ key, and
for TUNER, press key 2.

Finding out what code number you are using

If you have programmed your remote control by means of the automatic code scan, or if you have forgoten the code you have stored then the following procedure will replay the codes being used.

A. Press the TV key of your remote control for approx. 4 seconds until the LED flashes twice.
B. Enter code 0 0 2, using the numerical keys. The LED flashes twice.
C. Press key 1 and count the number of LED flashes. This number corresponds to the first digit of the code.
D. Press key 2 and count the number of LED flashes. This number corresponds to the second digit of the code (if the digit is 0, the LED does not flash).
E. Press key 3 and count the number of LED flashes. This number corresponds to the third digit of the code (if the digit is 0, the LED does not flash).
F. Steps C, D and E can be repeated as often as necessary.

To read the currently used code for the control of a VCR, SAT, DVD/AUX, CD, TAPE, TUNER or AMP device, proceed as described above for your TV SET. Complete steps A to F, pressing the VCR, SAT, DVD, CD, TAPE, TUNER or AMP key respectively.

Write down the code number as indicated by the LED.

Programming for AUX devices

If the remote you have purchased has a separate AUX key then this can be used to operate a second TV set, video recorder, satellite receiver/cable box, CD player, tape recorder, tuner or amplifier. To program your remote control for a second device, proceed as follows:

1. Press the AUX key of your remote control until the LED flashes twice.
2. Press
   TV key for a second TV set,
   VCR key for a second video recorder,
   SAT key for a second satellite receiver or cable box,
   keys SHIFT and CD for a second CD player,
   keys SHIFT and TAPE for a second tape recorder,
   keys SHIFT and TUNER for a second tuner,
   keys SHIFT and AMP for a second amplifier.
3. On the numerical keypad, enter a 3-digit code from the enclosed list.
4. The LED flashes twice, indicating that the code has been accepted.

Special functions of your remote control

Brightness / Colour / Contrast / etc.
Adjusting brightness / colour / contrast / bass / tremble / balance at your TV set, using the universal remote control:

1. Ensure that your remote control is set to TV (press TV key).
2. Press the SHIFT key.
3. Within 5 seconds, press
   1 for brightness, 2 for colour,
   3 for contrast, 4 for tremble,
   5 for bass, 6 for balance.
4. To adjust the settings use the VOL+ and VOL- keys.
5. After 5 seconds, your remote control returns to standard mode for the selection of channels.

OK key

- At TV level The basic settings of your TV SET are activated
- At TV level / menu Confirmation key for settings
- At VCR level Record button (press key twice)
- At SAT level Confirmation key for settings
- At DVD level Confirmation key for settings
- At TAPE level Record button (press key twice)

Please write down the 3-digit codes of your devices for future reference. Depending on the remote control model, you might have to reprogram me the universal control device after a battery change.

TV			
VCR			
SAT			
DVD/AUX			
CD			
TAPE			
TUNER			
AMPLIFIER			